

5' 3-Piece Aluminum Handle Assembly Instructions

CC263

- Line up the silver button on the piece with the threaded ends with the circular hole on the end of the all silver piece. Squeeze the buttons as you push the other piece over it to secure it.
- Repeat the same process with the buttons on the all silver piece and the piece with the end cap.
- 3. The buttons should protrude out of the holes to lock the pieces into place.
- 4. The handle is 60" long when assembled.
- Screw the handle into a broom thread bracket until securely tightened.